



Ersatzteile - Spare parts - Pièces de rechange - Reserveonderdelen - Parti di ricambio - Reservedele - Reserv



①	Elast. Verbindung	Elastic connector	JP43705
②	Niveaufassung	Level control	JP43712
③	Flansch	Flange	JP43706
④	Steuerung	Control unit	
	compli 400		JP46810
	compli 400 E		JP48526
⑤	Pumpe	Pump	
	compli 400		JP46753
	compli 400 E		JP46754
⑥	Rückschlagklappe	Reflux valve	JP43707
⑦	Steuerungsplatine	Control board	
	compli 400		JP46846
	compli 400 E		JP48527
⑧	Basisplatte	Base plate	JP43711
⑨	Überschiebmuffe	Collar	JP47287
⑩	Dichtband	Sealing tape	JP47966
		Anti floating	JP43709
⑮	Steckdichtung	Plug in seal	JP45099
⑯	Behälter	Tank	JP44859



①